


COOK PROCESSOR

MODELS:

5KCF0103EFP0 (Frosted Pearl - Europe)
5KCF0103EMS0 (Medallion Silver - Europe)
5KCF0103EOB0 (Onyx Black - Europe)
5KCF0103AAC0 (Almond Creme - Australia)
5KCF0103ACA0 (Candy Apple - Australia)
5KCF0103AER0 (Empire Red - Australia)
5KCF0103AFP0 (Frosted Pearl - Australia)
5KCF0103AMS0 (Medallion Silver - Australia)
5KCF0103AOB0 (Onyx Black - Australia)
5KCF0103BAC0 (Almond Creme - United Kingdom)
5KCF0103BCA0 (Candy Apple- United Kingdom)
5KCF0103BER0 (Empire Red - United Kingdom)
5KCF0103BFP0 (Frosted Pearl - United Kingdom)
5KCF0103BMS0 (Medallion Silver - United Kingdom)
5KCF0103BOB0 (Onyx Black - United Kingdom)
5KCF0104EBK0 (Imperial Black - Europe)

5KCF0104EFP0 (Frosted Pearl - Europe)
5KCF0104EMS0 (Medallion Silver - Europe)
5KCF0104EOB0 (Onyx Black - Europe)
5KCF0104AAC0 (Almond Creme - Australia)
5KCF0104ACA0 (Candy Apple - Australia)
5KCF0104AER0 (Empire Red - Australia)
5KCF0104AFP0 (Frosted Pearl - Australia)
5KCF0104AMS0 (Medallion Silver - Australia)
5KCF0104AOB0 (Onyx Black - Australia)
5KCF0104BAC0 (Almond Creme - United Kingdom)
5KCF0104BCA0 (Candy Apple- United Kingdom)
5KCF0104BER0 (Empire Red - United Kingdom)
5KCF0104BFP0 (Frosted Pearl - United Kingdom)
5KCF0104BMS0 (Medallion Silver - United Kingdom)
5KCF0104BOB0 (Onyx Black - United Kingdom)


UNIT PARTS



UNIT PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		Note: Parts below are the only items available for service. For all other parts issues, please contact Customer Service.	11	W10803161	PCBA, Speed Sensor	22	W10803160	Base
1		Literature Parts	12	W10769048	Belt	23	W10803184	Foot, Base
	W10755536	Use & Care Guide (Australia)	13	W10803183	Gear, Drive Pulley	24	W10803164	PCBA, Loudspeaker
	W10692501	Use & Care Guide (United Kingdom)	14	W10769049	Motor	25	W10803180	Panel, Control
2	W10769029	Pot, Cooking	15	W10803157	Screw	26	W10769054	Knob, Control Panel
3	W10803482	Adapter, Blade Drive	16	W10803162	PCBA, EMC			
4	W10803483	Coupling, Blade Drive Lock	17	W10769057	Switch, Power			
5	W10803182	Coupler, Gear Shaft	18	W10769055	Knob, Bowl Lock			
6	W10769050	Cap Assembly, Thermal Fuse	19		Display, Top			
7	W10803181	Switch Assembly, Interlock (5KCF0103*)		W10803176	Almond Creme			
	W10909930	Switch Assembly, Interlock (5KCF0104*)		W10897893	Imperial Black			
8	W10803158	Gasket, Terminal		W10803170	Candy Apple			
9	W10803156	Thermostat, Auxiliary		W10803169	Empire Red			
10	W10803159	PCBA, Main		W10803173	Frosted Pearl			
				W10803177	Medallion Silver			
			20	W10803165	Knob, Display			
			21		Power Cord			
				W10769052	Europe			
				W10803187	Australia			
				W10803185	United Kingdom			

ATTACHMENT PARTS



ATTACHMENT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10877418	Lid Assembly	6	W10769036	Basket, Steaming (Includes Lid, Middle and Lower Basket)	9	W10909932	Bowl Assembly (Includes Small Blade)
2	W10877420	Measuring Cup	7	W10909931	Wand, Stir Assist	10	W10769042	Doughblade
3	W10877419	Seal, Lid	8	W10769040	Multiblade			FOLLOWING PARTS NOT ILLUSTRATED
4	W10769045	Whisk, Egg				W10877421		Storage Case
5	W10769038	Steamer Basket, Inner						