

**KitchenAid®**




**7 SPEED CORDLESS HAND MIXER**

**MODELS:**

5KHMB732EBM0 (Black Matte)

5KHMB732EER0 (Empire Red)

# UNIT PARTS



# UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11418484	Literature Parts Use & Care Guide

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	W10531842	Beaters (includes Right and Left)
3	W11413727	Charger