

KitchenAid®

13-CUP FOOD PROCESSOR

MODELS:

5KFP1319EAC0 (Almond Cream)


5KFP1319EBM0 (Black Matte)

5KFP1319ECU0 (Contour Silver)

5KFP1319EER0 (Empire Red)

5KFP1319EOB0 (Onyx Black)

HOUSING UNIT AND ATTACHMENT PARTS



HOUSING UNIT AND ATTACHMENT PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W11519120	Externally Adjustable Slicing Disc	13	W11519131	Dicing Kit Clean Out Tool
	W11511621	Use & Care Guide	8	W11519121	Reversible Shredding Disc	14	W11519130	Storage Caddy
2		Base (Not Serviced)	9	W11519122	Multipurpose Blade	15	W11519129	Dicing Kit
3	W11519115	3 in1 Food Pusher Assembly	10	W11519123	Dough Blade			
4	W11567754	Work Bowl Cover (Includes Slicing Knob)	11	W11519124	Drive Adaptor (Upper)			
5	W11567753	13 Cup Work Bowl	12	W11519126	Drive Adaptor (Lower)			
6	W11519119	Refrigerator Lid						